

800-504-5684 info@bigdogbumpers.com www.bigdogbumpers.com

Ford F-150 2004-2008 Grille Guard

Note: In order to install this model, cutting or removing the air dam

is required.

- 1) Cut out the air dam underneath tow hook. Remove tow hook from truck frame and set aside for future installation. (see figure 1)
- 2) Remove nut found beside fog light. Slide mounting bracket over bolt exposed. Reinstall nut and secure in place with ½" x 6" bolt provided through bracket and truck frame. (see figure 2)
- 3) Lift grille guard up to the mounting brackets installed in step 2. Secure in place with (4) ½" nuts provided over bolts welded to brackets. Moderately tighten at this time.
- 4) Remove bolt behind air vent and discard.

 (see figure 3)



Figure 1




Figure 2



Figure 3

- 5)Secure top bracket B (for 06-08 models) provided, over cutout exposed in step 4 with (2) ½" x 2" bolts provided. Use backup plate behind truck frame and moderately tighten at this time. (see figure 4)
- 6) Secure opposite end of bracket to grille guard using (2) ½" x 1 ½" black carriage bolts provided.
- 7) Align grille guard and tighten all bolts with 75 lbs of torque. Reinstall tow hooks if applies.



Figure 4



Figure 5

Installation Kit Provided: (2) 1/2" x 1 1/2" black carriage bolts (1) top bracket A right (2) ½" black nuts (1) top bracket A left (2) 1/2" black washers (1) top bracket B right (2) 1/2"x 6" bolts (1) top bracket B left (2) ½" x 1 ½ " bolts (2) backup plates (8) ½" nuts (1) mount bracket right (10) 1/2" flat washers (1) mount bracket left

^{**} For 04-05 models use top bracket A provided. See figure 5 . **